



NOTES:

1. PULL BOXES ARE TO BE INSTALLED FLUSH WITH SIDEWALK. IF NO SIDEWALK, SET 1" ABOVE TOP OF CURB.
2. AFTER PULL BOX IS SET, BACKFILL WITH EXCAVATED MATERIAL AND THOROUGHLY COMPACT.
3. WHERE PULL BOXES ARE INSTALLED IN CONCRETE AREAS, 1/2" PRE-MOLDED EXPANSION JOINT SHALL BE INSTALLED AROUND PULL BOX.
4. CONDUCTORS SHALL HAVE A MINIMUM OF 36" SLACK FROM CONDUIT AND BELL.
5. PULL BOXES SHALL BE INSTALLED OUTSIDE OF CONCRETED AREAS, PEDESTRIAN TRAILS, AND VEHICULAR TRAFFIC AREAS.



**TOWN OF QUEEN CREEK
STANDARD DETAIL**

**STREET LIGHT
PULL BOX**

LT-2